

BROTHER

BROTHER DRUM UNITS	
DR150CL	Brother Drum Unit - HL4050CDN / HL4040 / HL4050 / HL4070 / MFC9440 / MFC9840 / MFC9450CN - (REPLACED DR130CL)
DR200	Brother Drum Unit - HL720 / HL730 / HL760 / Fax8000P / 8060P / MFC9000 / MFC9050 / MFC9060 / MFC9550 - 8 000 pgs
DR240CL-BK	Brother Drum - Black - HL3040CN / MFC9120CN / MFC9320CW / DCP9010CN - 15 000 pgs
DR240CL-CMY	Brother Drum - Individual Colour for Cyan, Magenta or Yellow
DR240CL	Brother Drum Multipack - 4 Drums (B,C,M,Y)
DR340CL	Brother Drum - HL4150CDN - 25 000 pgs
DR2025	Brother Drum Unit - DCP7010 / Fax2820 / HL2030 / HL2040 / HL2070N / MFC7225N / MFC7420 - (REPLACED DR2000)
DR2035	Brother Drum Unit - HL2035
DR2125	Brother Drum Unit - MFC7320 / DCP7030 / MFC7440N - (REPLACED DR2100)
DR2255	Brother Drum Unit - HL2270DW
DR3000	Brother Drum Unit - HL5150 / HL5170DN / MFC8220 / MFC8440 / MFC8840D - 20 000 pgs
DR3115	Brother Drum Unit 25 000 pgs - HL5240 / HL5250DN / HL5270DN / MFC8460DN / MFC8860DN - (REPLACED DR3100)
DR3215	Brother Drum Unit - HL5350DN / MFC8880 / MFC8370 / MFC8380
DR4000	Brother Drum Unit - HL6050 - 30 000 pgs
DR5500	Brother Drum Unit - HL7050 - 40 000 pgs
DR6000	Brother Drum Unit - HL1230 /1250 /1270 /1400 /1430 /1440 /1450 /1470N / Fax8350P / Fax8360P / MFC9650 / MFC9660 / MFC9750 / MFC9870 / MFC9880 - 9 000 pgs
DR7000	Brother Drum Unit - HL1650 / HL1850 / HL5070N / HL5050 / HL5030 / MFC8420 - 20 000 pgs
DR8000	Brother Drum Unit - Fax8070P / MFC9070 / MFC9180 - 8 000 pgs
BROTHER TONER CARTRIDGES	
TN04BK	Brother Black Toner Cartridge - HL2700CN / MFC9420CN
TN04C	Brother Cyan Toner Cartridge - HL2700CN / MFC9420CN
TN04M	Brother Magenta Toner Cartridge - HL2700CN / MFC9420CN
TN04Y	Brother Yellow Toner Cartridge - HL2700CN / MFC9420CN
TN12BK	Brother Black Toner Cartridge - HL4200CN - 9 000 pgs
TN12C	Brother Cyan Toner Cartridge - HL4200CN - 6 000 pgs
TN12M	Brother Magenta Toner Cartridge - HL4200CN - 6 000 pgs
TN12Y	Brother Yellow Toner Cartridge - HL4200CN - 6 000 pgs
TN155BK	Brother Black Toner Cartridge - HL4050CDN / HL4040 / HL4050 / HL4070 / MFC9440 / MFC9840 / MFC9450CN - (REPLACED TN135BK)
TN155C	Brother Cyan Toner Cartridge - HL4050CDN / HL4040 / HL4050 / HL4070 / MFC9440 / MFC9840 / MFC9450CN - (REPLACED TN135C)
TN155M	Brother Magenta Toner Cartridge - HL4050CDN / HL4040 / HL4050 / HL4070 / MFC9440 / MFC9840 / MFC9450CN - (REPLACED TN135M)
TN155Y	Brother Yellow Toner Cartridge - HL4050CDN / HL4040 / HL4050 / HL4070 / MFC9440 / MFC9840 / MFC9450CN - (REPLACED TN135Y)
TN1700	Brother Toner Cartridge - HL8050N - 17 000 pgs
TN200	Brother Toner Cartridge - HL720 / HL730 / HL760 / Fax8000P / Fax8060P / MFC9000 / MFC9050 / MFC9060 / MFC9550 - 2 400 pgs
TN2025	Brother Toner Cartridge - DCP7010 / Fax2820 / HL2030 / HL2040 / HL2070N / MFC7225N / MFC7420 - (REPLACED TN2000)
TN2035	Brother Toner Cartridge - HL2035
TN2150	Brother Toner Cartridge - MFC7320 / DCP7030 / MFC7440N - (REPLACED TN2120)
TN2280	Brother Toner Cartridge - HL2270DW
TN240BK	Brother Black Toner Cartridge - HL3040CN / MFC9120CN / MFC9320CW / DCP9010CN

