

# OKI

MONO Products - Toner Old Products	
01-09-1823	(9002395)OKI Toner Black - OL400e/ OL400ex/ OL410ex/ OL400w/ OP6e/ OP6ex/ OL600ex/ OL610ex/ OL810ex - 2 500 pgs
01-09-2012	(01107201)OKI Toner Black - OP6w/ OP8w/ OP8wLite/ OP8p/ OP8p+/ OP8im - 1 400 pgs
01-09-4004	(01103409)OKI Toner Black - B4100/ B4200/ B4250/ B4300/ B4350 - 2 500 pgs
01-09-4304	(01101213)OKI Toner Black - B4300/ B4350 - 6 000 pgs
01-09-6104	(09004058)OKI Toner Black - B6100 - 10 000 pgs
MONO Products - Drums Old Products	
01-09-1824	(09001042)OKI Drum - OL400e/ OL400ex/ OL410ex/ OL400w/ OP6e/ OP6ex/ OL600ex/ OL610ex/ OL810ex - 20 000 pgs
01-09-1896	(09001038)OKI Drum - OP4w/ OP4w+/ OP4m - 10 000 pgs
01-09-2016	(40433303)OKI Drum - OP10i/ OP10e/ OP10ex/ OP12i/n - 20 000 pgs
01-09-2015	(40709902)OKI Drum - OP6w/ OP8w/ OP8wLite/ OP8p/ OP8p+/ OP8im - 10 000 pgs
01-09-2017	(41019502)OKI Drum - OP20n/ OP20+/ OP24 - 30 000 pgs
01-09-4014	(42102802)OKI Drum - B4100/ B4200/ B4250/ B4300/ B4350 - 25 000 pgs
MONO Products - Toner Current Models	
01-09-2502	(09004447)OKI Toner Black - B2500 series - 2 000 pgs
01-09-2503	(09004391)OKI Toner Black - B2500 series - 4 000 pgs
01-09-0204	(01239901)OKI Toner Black - MB260 / MB280 / MB290 - 3 000 pgs
01-09-0205	(01240001)OKI Toner Black - MB260 / MB280 / MB290 - 5 500 pgs
01-09-2224	(43640307)OKI Toner Black - B2000 / B2200 / B2400 / B2400n - 2 000 pgs
01-09-4446	(43502306)OKI Toner Black - B4400 / B4600 - 3 000 pgs
01-09-4661	(43502004)OKI Toner Black - B4600 - 7 000 pgs
01-09-0404	(43979107)OKI Toner Black - B410/ B430/ B440/ MB460/ MB470/ MB4803 - 3 500 pgs
01-09-0405	(43979211)OKI Toner Black - B430/ B440/ MB460/ MB470. MB480 - 7 000 pgs
01-09-4404	(43979218)OKI Toner Black - B440 / MB480 - 12 000 pgs
01-09-4104	(44574705)OKI Toner Black - B411 / B431 - 3 000 pgs
01-09-4105	(44574906)OKI Toner Black - B431 - 10 000 pgs
01-09-6204	(09004078)OKI Toner Black - B6200 / B6300 / B6250 - 10 000 pgs
01-09-6205	(01225401)OKI Toner Black - B6250 - 6 000 pgs
01-09-6304	(09004079)OKI Toner Black - B6300 - 17 000 pgs
01-09-6504	(09004461)OKI Toner Black - B6500 - 13 000 pgs
01-09-6505	(09004462)OKI Toner Black - B6500 - 22 000 pgs
01-09-7704	(01279001)OKI Toner Black - B710 / B720 / B730 - 15 000 pgs
01-09-7204	(01279101)OKI Toner Black - B720 - 20 000 pgs
01-09-7304	(01279201)OKI Toner Black - B730 - 25 000 pgs
01-09-8304	(09004019)OKI Toner Black - B8300 - 27 000 pgs
01-09-0934	(01221601)OKI Toner Black - B930 - 30 000 pgs
Mono Products - Drums Current Products	
01-09-2214	(43650302)OKI Drum - B2200 / B2400 / B2400n - 15 000 pgs
01-09-4447	(43501902)OKI Drum - B4400 / B4600 - 25 000 pgs
01-09-0414	(43979002)OKI Drum - B410 / B430/ B440 - 25 000 pgs
01-09-4114	(44574302)OKI Drum - B411 / B431 - 25 000 pgs

01-09-8305	(09004020)OKI Drum - B8300 - 100 000 pgs
01-09-9114	(01221701)OKI Drum - B930 - 60 000 pgs
	<b>COLOUR Products - Toners C100 Series</b>
01-09-0101	(44250725)OKI Toner Yellow - C110 / C130 / MC160 1 500 pgs
01-09-0102	(44250726)OKI Toner Magenta - C110 / C130 / MC160 - 1 5000 pgs
01-09-0103	(44250727)OKI Toner Cyan - C110 / C130 / MC160 - 1 500 pgs
01-09-0101H	(44250729)OKI Toner Yellow - C110 / C130 / MC160 - 2 500 pgs
01-09-0102H	(44250730)OKI Toner Magenta - C110 / C130 / MC160 - 2 500 pgs
01-09-0103H	(44250731)OKI Toner Cyan - C110 / C130 / MC160 - 2 500 pgs
01-09-0104H	(44250732)OKI Toner Black - C110 / C130 / MC160 - 2 500 pgs
	<b>COLOUR Products - Drums C100 Series</b>
01-09-0115	(44250801)OKI Drum - C110 / C130 / MC160
	<b>COLOUR Products - Toners C3000 Series</b>
01-09-3101	(42804574)OKI Toner Yellow - C3100 only - 3 000 pgs
01-09-3102	(42804575)OKI Toner Magenta - C3100 only - 3 000 pgs
01-09-3103	(42804576)OKI Toner Cyan - C3100 only - 3 000 pgs
01-09-3104	(42804577)OKI Toner Black - C3100 only - 3 000 pgs
01-09-3201	(42804578)OKI Toner Yellow - C3200 only - 3 000 pgs
01-09-3201L	(43034813)OKI Toner Yellow - C3200 only - 1 500 pgs
01-09-3202	(42804579)OKI Toner Magenta - C3200 only - 3 000 pgs
01-09-3202L	(43034814)OKI Toner Magenta - C3200 only - 1 500 pgs
01-09-3203	(2804580)OKI Toner Cyan - C3200 only - 3 000 pgs
01-09-3203L	(43034815)OKI Toner Cyan - C3200 only - 1 500 pgs
01-09-3204	(42804581)OKI Toner Black - C3200 only - 3 000 pgs
01-09-3204L	(43034816)OKI Toner Black - C3200 only - 1 500 pgs
01-09-3601	(43459441)OKI Toner Yellow - C3450 / C3300 / C3400 / C3450n / C3600 - 1 500 pgs
01-09-3602	(43459442)OKI Toner Magenta - C3450 / C3300 / C3400 / C3450n / C3600 - 1 500 pgs
01-09-3603	(43459443)OKI Toner Cyan - C3450 / C3300 / C3400 / C3450n / C3600 - 1 500 pgs
01-09-3604	(43459444)OKI Toner Black - C3450 / C3300 / C3400 / C3450n / C3600 - 1 500 pgs
01-09-3451	(43459345)OKI Toner Yellow - C3300 / C3400 / C3450n / C3600 - 2 500 pgs
01-09-3452	(43459346)OKI Toner Magenta - C3300 / C3400 / C3450n / C3600 - 2 500 pgs
01-09-3453	(43459347)OKI Toner Cyan - C3300 / C3400 / C3450n / C3600 - 2 500 pgs
01-09-3454	(43459348)OKI Toner Black - C3300 / C3400 / C3450n / C3600 - 2 500 pgs
01-09-3501	(43459373)OKI Toner Yellow - C3520 MFP / C3530MFP - 2 500 pgs
01-09-3502	(43459374)OKI Toner Magenta - C3520MFP / C3530MFP - 2 500 pgs
01-09-3503	(43459375)OKI Toner Cyan - C3520MFP / C3530MFP - 2 500 pgs
01-09-3504	(43459336)OKI Toner Black - C3520MFP / C3530MFP - 2 500 pgs
01-09-0301	(44469714)OKI Toner Yellow - C310 / C330 / C510 / C530 / MC351 / MC361 / MC56 - 2 000 pgs
01-09-0302	(44469715)OKI Toner Magenta - C310 / C330 / C510 / C530 / MC351 / MC361 / MC56 - 2 000 pgs
01-09-0303	(44469716)OKI Toner Cyan - C310 / C330 / C510 / C530 / MC351 / MC361 / MC56 - 2 000 pgs
01-09-0304	(44469809)OKI Toner Black - C310 / C330 / C510 / C530 / MC351 / MC361 / MC56 - 3 500 pgs

<b>COLOUR Products - Drums C3000 Series</b>	
01-09-3111	(42126641)OKI Drum Yellow - C3100 only - 14 000 pgs
01-09-3112	(42126642)OKI Drum Magenta - C3100 only - 14 000 pgs
01-09-3113	(42126643)OKI Drum Cyan - C3100 only - 14 000 pgs
01-09-3114	(42126644)OKI Drum Black - C3100 only - 14 000 pgs
01-09-3211	(42126662)OKI Drum Yellow - C3200 only - 14 000 pgs
01-09-3212	(42126663)OKI Drum Magenta - C3200 only - 14 000 pgs
01-09-3213	(42126664)OKI Drum Cyan - C3200 only - 14 000 pgs
01-09-3214	(42126665)OKI Drum Black - C3200 only - 14 000 pgs
01-09-3311	(43460205)OKI Drum Yellow - C3300 / C3400 / C3450n / C3600 - 15 000 pgs
01-09-3312	(43460206)OKI Drum Magenta - C3300 / C3400 / C3450n / C3600 - 15 000 pgs
01-09-3313	(43460207)OKI Drum Cyan - C3300 / C3400 / C3450n / C3600 - 15 000 pgs
01-09-3314	(43460208)OKI Drum Black - C3300 / C3400 / C3450n / C3600 - 15 000 pgs
01-09-3511	(43460221)OKI Drum Yellow - C3520 MFP/C3530MFP - 15 000 pgs
01-09-3512	(43460222)OKI Drum Magenta - C3520 MFP/C3530MFP - 15 000 pgs
01-09-3513	(43460223)OKI Drum Cyan - C3520 MFP/C3530MFP - 15 000 pgs
01-09-3514	(43460224)OKI Drum Black - C3520 MFP/C3530MFP - 15 000 pgs
01-09-0314	(44494202)OKI Drum - C310/330/510/530 - 20 000 pgs
<b>COLOUR Products - Toners C5000 Series</b>	
01-09-5101	(42127488)OKI Toner Yellow C5100 / C5200 / C5300 / C5400 - 5 000 pgs
01-09-5102	(42127489)OKI Toner Magenta - C5100 / C5200 / C5300 / C5400 - 5 000 pgs
01-09-5103	(42127490)OKI Toner Cyan - C5100 / C5200 / C5300 / C5400 - 5 000 pgs
01-09-5104	(42127491)OKI Toner - C5100 / C5200 / C5300 / C5400 - 5 000 pgs
01-09-5105	(42403002)OKI Toner Rainbow Pack CMYK - C5100 / C5200 / C5300 / C5400 - 5 000 pgs
01-09-5501	(42127492)OKI Toner Yellow - C5250 / C5450 / C5510MFP / C5540MFP - 5 000 pgs
01-09-5502	(42127493)OKI Toner Magenta - C5250 / C5450 / C5510MFP / C5540MFP - 5 000 pgs
01-09-5503	(42127494)OKI Toner Cyan - C5250 / C5450 / C5510MFP / C5540MFP - 5 000 pgs
01-09-5504	(42127495)OKI Toner Black - C5250 / C5450 / C5510MFP / C5540MFP - 5 000 pgs
01-09-5505	(42403006)OKI Toner Rainbow Pack CMYK - C5250 / C5450 / C5510MFP / C5540MFP - 5 000 pgs
01-09-5501L	(42804570)OKI Toner Yellow - C5250 / C5450 / C5510MFP / C5540MFP - 3 000 pgs
01-09-5502L	(42804571)OKI Toner Magenta - C5250 / C5450 / C5510MFP / C5540MFP - 3 000 pgs
01-09-5503L	(42804572)OKI Toner Cyan - C5250 / C5450 / C5510MFP / C5540MFP - 3 000 pgs
01-09-5504L	(42804573)OKI Toner Black - C5250 / C5450 / C5510MFP / C5540MFP - 3 000 pgs
01-09-5601	(43381921)OKI Toner Yellow - C5600 / C5700 - 2 000 pgs
01-09-5602	(43381922)OKI Toner Magenta - C5600 / C5700 - 2 000 pgs
01-09-5603	(43381923)OKI Toner Cyan - C5600 / C5700n - 2 000 pgs
01-09-5604	(43324440)OKI Toner Black - C5600 / C5700 - 6 000 pgs
01-09-5751	(43872321)OKI Toner Yellow - C5650 / C5750 - 2 000 pgs
01-09-5752	(43872322)OKI Toner Magenta - C5650 / C5750 - 2 000 pgs
01-09-5753	(43872323)OKI Toner Cyan - C5650 / C5750 - 2 000 pgs
01-09-5754	(43865740)OKI Toner Black - C5650/C5750 - 8 000 pgs
01-09-5801	(43324441)OKI Toner Yellow - C5800 / C5900 / C5550 MFP - 5 000 pgs
01-09-5802	(43324442)OKI Toner Magenta - C5800 / C5900 / C5550 MFP - 5 000 pgs
01-09-5803	(43324443)OKI Toner Cyan - C5800 / C5900 / C5550 MFP - 5 000 pgs
01-09-5804	(43324444)OKI Toner - Black C5800 / C5900 / C5550 MFP - 6 000 pgs

01-09-5951	(43865741)OKI Toner Yellow - C5850 / C5950 / MC560 - 6 000 pgs
01-09-5952	(43865742)OKI Toner Magenta - C5850 / C5950 / MC560 - 6 000 pgs
01-09-5953	(43865743)OKI Toner Cyan - C5850 / C5950 / MC560 - 6 000 pgs
01-09-5954	(43865744)OKI Toner Black - C5850 / C5950 / MC560 - 8 000 pgs
01-09-0501	(44469752)OKI Toner Yellow - C510 / C530 / MC561 - 5 000 pgs
01-09-0502	(44469753)OKI Toner Magenta - C510 / C530 / MC561 - 5 000 pgs
01-09-0503	(44469754)OKI Toner Cyan - C510 / C530 / MC561 - 5 000 pgs
01-09-0504	(44973540)OKI Toner Black - C510 / C530 / MC561 - 5 000 pgs
	<b>COLOUR Products - Drums C5000 Series</b>
01-09-5111	(42126605)OKI Drum Yellow - C5100 / C5200 / C5300 / C5400 - 17 000 pgs
01-09-5112	(42126606)OKI Drum Magenta - C5100 / C5200 / C5300 / C5400 - 17 000 pgs
01-09-5113	(42126607)OKI Drum Cyan - C5100 / C5200 / C5300 / C5400 - 17 000 pgs
01-09-5114	(42126608)OKI Drum Black - C5100 / C5200 / C5300 / C5400 - 17 000 pgs
01-09-5511	(42126670)OKI Drum Yellow - C5250 / C5450 / C5510MFP / C5540MFP -17 000 pgs
01-09-5512	(42126671)OKI Drum Magenta - C5250 / C5450 / C5510MFP / C5540MFP - 17 000 pgs
01-09-5513	(42126672)OKI Drum Cyan - C5250 / C5450 / C5510MFP / C5540MFP - 17 000 pgs
01-09-5514	(42126673)OKI Drum Black - C5250 / C5450 / C5510MFP / C5540MFP - 17 000 pgs
01-09-5611	(43381705)OKI Drum Yellow - C5600 / C5700 - 20 000 pgs
01-09-5612	(43381706)OKI Drum Magenta - C5600 / C5700 - 20 000 pgs
01-09-5613	(43381707)OKI Drum Cyan - C5600 / C5700 - 20 000 pgs
01-09-5614	(43381708)OKI Drum Black - C5600 / C5700 - 20 000 pgs
01-09-5711	(43870005)OKI Drum Yellow - C5650 / C5750 - 20 000 pgs
01-09-5712	(43870006)OKI Drum Magenta - C5650 / C5750 - 20 000 pgs
01-09-5713	(43870007)OKI Drum Cyan - C5650 / C5750 - 20 000 pgs
01-09-5714	(43870008)OKI Drum Black - C5650 / C5750 - 20 000 pgs
01-09-5811	(43381721)OKI Drum Yellow - C5800 / C5900 / C5550MFP - 20 000 pgs
01-09-5812	(43381722)OKI Drum Magenta - C5800 / C5900 / C5550MFP - 20 000 pgs
01-09-5813	(43381723)OKI Drum Cyan - C5800 / C5900 / C5550MFP - 20 000 pgs
01-09-5814	(43381724)OKI Drum Black - C5800 / C5900 / C5550MFP - 20 000 pgs
01-09-5911	(43870021)OKI Drum Yellow - C5850 / C5950 - 20 000 pgs
01-09-5912	(43870022)OKI Drum Magenta - C5850 / C5950 - 20 000 pgs
01-09-5913	(43870023)OKI Drum Cyan - C5850 / C5950 - 20 000 pgs
01-09-5914	(43870024)OKI Drum Black - C5850 / C5950 - 20 000 pgs
	<b>COLOUR PRODUCTS - Toners C600 Series</b>
01-09-0601	(44315321)OKI Toner Yellow - C610 - 6 000 pgs
01-09-0602	(44315322)OKI Toner Magenta - C610 - 6 000 pgs
01-09-0603	(44315323)OKI Toner Cyan - C610 - 6 000 pgs
01-09-0604	(44315324)OKI Toner Black C610 - 8 000 pgs
	<b>COLOUR Products - Drums C600 Series</b>
01-09-0611	(44315105)OKI Drum Yellow - C610 - 20 000 pgs
01-09-0612	(44315106)OKI Drum Magenta - C610 - 20 000 pgs
01-09-0613	(44315107)OKI Drum Cyan - C610 - 20 000 pgs
01-09-0614	(44315108)OKI Drum Black - C610 - 20 000 pgs

<b>COLOUR Products - Toners C7000 Series</b>	
01-09-7001	(41304285)OKI Toner Yellow - C7200 / C7400 - 10 000 pgs
01-09-7002	(41304286)OKI Toner Magenta - C7200 / C7400 - 10 000 pgs
01-09-7003	(41304287)OKI Toner Cyan - C7200 / C7400 - 10 000 pgs
01-09-7004	(41304288)OKI Toner Black - C7200 / C7400 - 10 000 pgs
01-09-7101	(41963083)OKI Toner Yellow - C7100 / C7300 / C7350 / C7500 - 10 000 pgs
01-09-7102	(41963084)OKI Toner Magenta - C7100 / C7300 / C7350 / C7500 - 10 000 pgs
01-09-7103	(41963085)OKI Toner Cyan - C7100 / C7300 / C7350 / C7500 - 10 000 pgs
01-09-7104	(41963086)OKI Toner Black - C7100 / C7300 / C7350 / C7500 - 10 000 pgs
01-09-7105	(01101001)OKI Toner Kit CMYK - C7100 / C7300 / C7350 / C7500 - 10 000 pgs
01-09-0701	(44318621)OKI Toner Yellow - C710 / C711 - 11 500 pgs
01-09-0702	(44318622)OKI Toner Magenta - C710 / C711 - 11 500 pgs
01-09-0703	(44318623)OKI Toner Cyan - C710 / C711 - 11 500 pgs
01-09-0704	(44318624)OKI Toner Black - C710 / C711 - 11 000 pgs
<b>COLOUR Products - Drums C7000 Series</b>	
01-09-7011	(41304109)OKI Drum Yellow - C7200 / C7400 - 30 000 pgs
01-09-7012	(41304110)OKI Drum Magenta - C7200 / C7400 - 30 000 pgs
01-09-7013	(41304111)OKI Drum Cyan - C7200 / C7400 - 30 000 pgs
01-09-7014	(41304112)OKI Drum Black - C7200 / C7400 - 30 000 pgs
01-09-7111	(41962805)OKI Drum Yellow - C7100 / C7300 / C7350 / C7500 - 23 000 pgs
01-09-7112	(41962806)OKI Drum Magenta - C7100 / C7300 / C7350 / C7500 - 23 000 pgs
01-09-7113	(41962807)OKI Drum Cyan - C7100 / C7300 / C7350 / C7500 - 23 000 pgs
01-09-7114	(41962808)OKI Drum Black - C7100 / C7300 / C7350 / C7500
01-09-0711	(43913805)OKI Drum Yellow - C710 - 15 000 pgs
01-09-0712	(43913806)OKI Drum Magenta - C710 - 15 000 pgs
01-09-0713	(43913807)OKI Drum Cyan - C710 - 15 000 pgs
01-09-0714	(43913808)OKI Drum Black - C710 - 20 000 pgs
01-09-7110	(44318505)OKI Drum Yellow - C711 - 20 000 pgs
01-09-7120	(44318506)OKI Drum Magenta - C711 - 20 000 pgs
01-09-7130	(44318507)OKI Drum Cyan - C711 - 20 000 pgs
01-09-7140	(44318508)OKI Drum Black - C711 - 20 000 pgs
<b>COLOUR Products - Toners C8000 Series</b>	
01-09-8601	(43487721)OKI Toner Yellow - C8600 / C8800 - 6 000 pgs
01-09-8602	(43487722)OKI Toner Magenta - C8600 / C8800 - 6 000 pgs
01-09-8603	(43487723)OKI Toner Cyan - C8600 / C8800 - 6 000 pgs
01-09-8604	(43487724)OKI Toner Black - C8600 / C8800 - 6 000 pgs
01-09-8301	(44059117)OKI Toner Yellow - C810 / C830 - 8 000 pgs
01-09-8302	(44059118)OKI Toner Magenta - C810 / C830 - 8 000 pgs
01-09-8303	(44059119)OKI Toner Cyan - C810 / C830 - 8 000 pgs
01-09-8340	(44059120)OKI Toner Black - C810 / C830 - 8 000 pgs
01-09-0801	(44643005)OKI Toner Yellow - C801 / C821 - 7 300 pgs
01-09-0802	(44643006)OKI Toner Magenta - C801 / C821 - 7 300 pgs
01-09-0803	(44643007)OKI Toner Cyan - C801 / C821 - 7 300 pgs
01-09-0804	(44643008)OKI Toner Black - C801 / C821 - 7 300 pgs
01-09-8101	(44059225)OKI Toner Yellow - MC860 - 10 000 pgs

01-09-8102	(4059226)OKI Toner Magenta - MC860 - 10 000 pgs
01-09-8103	(44059227)OKI Toner Cyan - MC860 - 10 000 pgs
01-09-8104	(44059228)OKI Toner Black - MC860 - 9 500 pgs
	<b>COLOUR Products - Drums C8000 Series</b>
01-09-8611	(43449013)OKI Drum Yellow - C8600 / C8800 - 20 000 pgs
01-09-8612	(43449014)OKI Drum Magenta - C8600 / C8800 - 20 000 pgs
01-09-8613	(43449015)OKI Drum Cyan - C8600 / C8800 - 20 000 pgs
01-09-8614	(43449016)OKI Drum Black - C8600 / C8800 - 20 000 pgs
01-09-8111	(44064009)OKI Drum Yellow - C810 / C830 / MC860 / C801 / C821 - 20 000 pgs
01-09-8112	(44064010)OKI Drum Magenta - C810 / C830 / MC860 / C801 / C821 - 20 000 pgs
01-09-8113	(44064011)OKI Drum Cyan - C810 / C830 / MC860 / C801 / C821 - 20 000 pgs
01-09-8114	(44064012)OKI Drum Black - C810 / C830 / MC860 / C801 / C821 - 20 000 pgs
	<b>COLOUR Products - Toners C9000 Series</b>
01-09-9001	(41515289)OKI Toner Yellow - C9200 / C9400 - 15 000 pgs
01-09-9002	(41515290)OKI Toner Magenta - C9200 / C9400 - 15 000 pgs
01-09-9003	(41515291)OKI Toner Cyan - C9200 / C9400 - 15 000 pgs
01-09-9004	(41515292)OKI Toner Black - C9200 / C9400 - 15 000 pgs
01-09-9301	(41963675)OKI Toner Yellow - C9300 / C9500 - 15 000 pgs
01-09-9302	(41963676)OKI Toner Magenta - C9300 / C9500 - 15 000 pgs
01-09-9303	(41963677)OKI Toner Cyan - C9300 / C9500 - 15 000 pgs
01-09-9304	(41963678)OKI Toner Black - C9300 / C9500 - 15 000 pgs
01-09-9305	(01101101)OKI Toner Kit CMYK - C9300 / C9500 - 15 000 pgs
01-09-9101	(44036021)OKI Toner Yellow - C910 - 15 000 pgs
01-09-9102	(44036022)OKI Toner Magenta - C910 - 15 000 pgs
01-09-9103	(44036023)OKI Toner Cyan - C910 - 15 000 pgs
01-09-9104	(44036024)OKI Toner Black - C910 - 15 000 pgs
01-09-9601	(42918961)OKI Toner Yellow - C9600 / C9800 / C9800MFP / C9650 / C9850 / C9850MFP - 15 000 pgs
01-09-9602	(42918962)OKI Toner Magenta - C9600 / C9800 / C9800MFP / C9650 / C9850 / C9850MFP - 15 000 pgs
01-09-9603	(42918963)OKI Toner Cyan - C9600 / C9800 / C9800MFP / C9650 / C9850 / C9850MFP - 15 000 pgs
01-09-9604	(42918964)OKI Toner Black - C9600 / C9800 / C9800MFP / C9650 / C9850 / C9850MFP - 15 000 pgs
01-09-9605	(43112702)OKI Toner Rainbow Pack CMYK - C9600 / C9800 / C9800MFP / C9650 / C9850 / C9850MFP - 15 000 pgs
	<b>COLOUR Products - Drums C9000 Series</b>
01-09-9011	(41514709)OKI Drum Yellow - C9200 / C9400 - 39 000 pgs
01-09-9012	(41514710)OKI Drum Magenta - C9200 / C9400 - 39 000 pgs
01-09-9013	(41514711)OKI Drum Cyan - C9200 / C9400 - 39 000 pgs
01-09-9014	(41514712)OKI Drum Black - C9200 / C9400 - 39 000 pgs
01-09-9311	(41963405)OKI Drum Yellow - C9300 / C9500 - 30 000 pgs
01-09-9312	(41963406)OKI Drum Magenta - C9300 / C9500 - 30 000 pgs
01-09-9313	(41963407)OKI Drum Cyan - C9300 / C9500 - 30 000 pgs
01-09-9314	(41963408)OKI Drum Black - C9300 / C9500 - 30 000 pgs
01-09-0911	(44035517)OKI Drum Yellow - C910 - 20 000 pgs
01-09-0912	(44035518)OKI Drum Magenta - C910 - 20 000 pgs

01-09-0913	(44035519)OKI Drum Cyan - C910 - 20 000 pgs
01-09-0914	944035520)OKI Drum Black - C910 - 20 000 pgs
01-09-9611	(42918105)OKI Drum Yellow - C9600 / C9800 / C9800MFP / C9650 / C9850 / C9850MFP - 30 000 pgs
01-09-9612	(42918106)OKI Drum Magenta - C9600 / C9800 / C9800MFP / C9650 / C9850 / C9850MFP- 30 000 pgs
01-09-9613	(42918107)OKI Drum Cyan - C9600 / C9800 / C9800MFP / C9650 / C9850 / C9850MFP - 30 000 pgs
01-09-9614	(42918108)OKI Drum Black - C9600 / C9800 / C9800MFP / C9650 / C9850 / C9850MFP - 30 000 pgs
<b>ES Range</b>	
<b>A4 Colour Printer Consumables</b>	
44973509	OKI Toner Yellow - ES4531 - 6000 pgs
44973510	OKI Toner Magenta - ES4531 - 6000pgs
44973511	OKI Toner Cyan - ES4531 - 6000pgs
44973512	OKI Toner Black - ES4531 - 7000pgs
01282903	OKI Drum CMYK - ES4531 - 20 000pgs
01-09-5323	OKI Fuser Unit - ES4531 - 60 000pgs
01-09-5300	OKI Transfer Belt - ES4531 - 60 000pgs
01-03-7401	OKI Toner Yellow - ES7411dn - 10 000pgs
01-03-7402	OKI Toner Magenta - ES7411dn - 10 000pgs
01-03-7403	OKI Toner Black - ES7411dn - 10 000pgs
01-03-7404	OKI Toner Cyan - ES7411dn - 10 000pgs
01-03-7411	OKI EP Cartridge Yellow - ES7411dn - 20 000pgs
01-03-7412	OKI EP Cartridge Magenta - ES7411dn - 20 000pgs
01-03-7413	OKI EP Cartridge Cyan - ES7411dn - 20 000pgs
01-03-7414	OKI EP Cartridge Black - ES7411dn - 20 000pgs
01-09-0623	OKI Fuser Unit - ES7411dn - 60 000pgs
01-09-0600	OKI Transfer Belt - ES7411dn - 60 000pgs
<b>A4 Colour MFP Consumables</b>	
44973509	OKI Toner Yellow - ES3452 / ES5462 mfp - 6000pgs
44973510	OKI Toner Magenta - ES3452 / ES5462 mfp - 6000pgs
44973511	OKI Toner Cyan - ES3452 / ES5462 mfp - 6000pgs
44973512	OKI Toner Black - ES3452 / ES5462 mfp - 6000pgs
01282903	OKI Drum CMYK - ES3452 / ES5462 mfp - 20 000pgs
01-09-5323	OKI Fuser Unit - ES3452 / ES5462 mfp - 60 000pgs
01-09-5300	OKI Transfer Belt - ES3452 / ES5462 mfp - 60 000pgs
<b>A3 Colour Printer Consumables</b>	
01-03-8401	OKI Toner Yellow - ES8430dn - 7000pgs
01-03-8402	OKI Toner Magenta - ES8430dn - 7000pgs
01-03-8403	OKI Toner Cyan - ES8430dn - 7000pgs
01-03-8404	OKI Toner Black - ES8430dn - 7000pgs
01-03-8411	OKI EP Cartridge Yellow - ES8430dn - 20 000pgs
01-03-8412	OKI EP Cartridge Magenta - ES8430dn - 20 000pgs
01-03-8413	OKI EP Cartridge Cyan - ES8430dn - 20 000pgs
01-03-8414	OKI EP Cartridge Black - ES8430dn - 20 000pgs
01-09-8623	OKI Fuser Unit - ES8430dn - 100 000pgs

01-09-8600	OKI Transfer Belt - ES8430dn - 80 000pgs
01-03-3663	OKI Toner Cyan - ES3640a3 Sys1+ / ES3640a3 Sys3+ / ES3640PRO - 16 500pgs
01-03-3662	OKI Toner Magenta - ES3640a3 Sys1+ / ES3640a3 Sys3+ / ES3640PRO - 16 500pgs
01-03-3661	OKI Toner Yellow - ES3640a3 Sys1+ / ES3640a3 Sys3+ / ES3640PRO - 16 500pgs
01-03-3664	OKI Toner Black - ES3640a3 Sys1+ / ES3640a3 Sys3+ / ES3640PRO - 16 500pgs
01-03-3013	OKI Drum Cyan - ES3640a3 Sys1+ / ES3640a3 Sys3+ / ES3640PRO - 16 500pgs
01-03-3012	OKI Drum Magenta - ES3640a3 Sys1+ / ES3640a3 Sys3+ / ES3640PRO - 16 500pgs
01-03-3011	OKI Drum Yellow - ES3640a3 Sys1+ / ES3640a3 Sys3+ / ES3640PRO - 16 500pgs
01-03-3014	OKI Drum Black - ES3640a3 Sys1+ / ES3640a3 Sys3+ / ES3640PRO - 16 500pgs
01-09-9623	OKI Fuser Unit - ES3640a3 Sys1+ / ES3640a3 Sys3+ / ES3640PRO - 100 000pgs
01-09-9600	OKI Transfer Belt - ES3640a3 Sys1+ / ES3640a3 Sys3+ / ES3640PRO - 100 000pgs
01-03-3621	OKI Staples for ES3640a3 Sys1+ / ES3640a3 Sys3+ / ES3640PRO (3 x 5000)
01-09-9622	OKI Waste Bottle - ES3640a3 Sys1+ / ES3640a3 Sys3+ / ES3640PRO 30 000pgs
01-03-9401	OKI Toner Yellow - ES9410dn - 15 000pgs
01-03-9402	OKI Toner Magenta - ES9410dn - 15 000pgs
01-03-9403	OKI Toner Cyan - ES9410dn - 15 000pgs
01-03-9404	OKI Toner Black - ES9410dn - 15 000pgs
01-03-9411	OKI EP Cartridge Yellow - ES9410dn - 20 000pgs
01-03-9412	OKI EP Cartridge Magenta - ES9410dn - 20 000pgs
01-03-9413	OKI EP Cartridge Cyan - ES9410dn - 20 000pgs
01-03-9414	OKI EP Cartridge Black - ES9410dn - 20 000pgs
01-09-9623	OKI Fuser Unit - ES9410dn 100 000pgs
01-09-9600	OkI Transfer Belt - ES9410dn - 100 000pgs
01-09-9622	OKI TWBOX - ES9410dn - 20 000pgs
01-03-3621	OKI Staple - ES9410dn - 15 000pgs
	<b>A3 Colour MFP Consumables</b>
01-03-8451	OKI Toner Yellow - ES8451 / ES8461 mfp 9000pgs
01-03-8462	OKI Toner Magenta - ES8451 / ES8461 mfp 9000pgs
01-03-8463	OKI Toner Cyan - ES8451 / ES8461 mfp 9000pgs
01-03-8464	OKI Toner Black - ES8451 / ES8461 mfp 9000pgs
01-03-8411	OKI EP Cartridge Yellow - ES8451 / ES8461 mfp 20 000pgs
01-03-8412	OKI EP Cartridge Magenta - ES8451 / ES8461 mfp 20 000pgs
01-03-8413	OKI EP Cartridge Cyan - ES8451 / ES8461 mfp 20 000pgs
01-03-8414	OKI EP Cartridge Black - ES8451 / ES8461 mfp 20 000pgs
01-09-8623	OKI Fuser Unit - ES8451 / ES8461 mfp 100 000pgs
01-09-8600	OKI Transfer Belt - ES8451 / ES8461 mfp - 80 000pgs
01-03-3663	OKI Toner Cyan - ES3640 PROMFP - 16 500pgs
01-03-3662	OKI Toner Magenta - ES3640 PROMFP - 16 500pgs
01-03-3661	OKI Toner Yellow - ES3640 PROMFP - 16 500pgs
01-03-3664	OKI Toner Black - ES3640 PROMFP - 16 500pgs
01-03-3013	OKI Drum Cyan - ES3640 PROMFP - 30 000pgs
01-03-3012	OKI Drum Magenta - ES3640 PROMFP - 30 000pgs
01-03-3011	OKI Drum Yellow - ES3640 PROMFP - 30 000pgs
01-03-3014	OKI Drum Black - ES3640 PROMFP - 30 000pgs
01-09-9623	OKI Fuser Unit - ES3640 PROMFP - 100 000pgs
01-09-9600	OKI Transfer Belt - ES3640 PROMFP - 100 000pgs



01-09-9622	OKI Waste Bottle - ES3640 PROMFP - 30 000pgs
	<b>ES Mono Consumables</b>
01-03-4102	OKI Toner Black - ES4140 - 12000pgs
01-03-4111	OKI Drum Black - ES4140 - 25 000pgs
01-03-4101	OKI Toner Black - ES4131dn / ES4191 - 12 000pgs
01-03-4112	OKI Drum Black - ES4131dn / ES4191 - 25 000pgs
01-03-6101	OKI Print Cartridge - ES6150 - 22 000pgs
01-03-7131	OKI Print Cartridge - ES7120 / ES7130 - 25 000pgs
01-03-8101	OKI Toner Black - ES8140 - 20 000pgs
01-03-9101	OKI Toner Black - ES9130dn - 30 000pgs
01-03-9111	OKI EP Cartridge Black - ES9130dn - 60 000pgs
01264301	OKI Maintenance Kit - ES9130dn